

# INSTRUCTIONS

## Option - Trousse de thermostat

L'INSTALLATION DOIT ÊTRE EXÉCUTÉE PAR UN TECHNICIEN QUALIFIÉ




### ATTENTION

**COUPER L'ALIMENTATION  
AVANT DE MANIPULER LES CIRCUITS INTERNES**

#### INSTALLATION

1. Fixez le thermostat à l'extrémité gauche (standard) ou à l'extrémité droite de la grille du devant.
2. Utilisez une paire de pinces pour élargir la grille vis-à-vis le thermostat.
3. Insérez le bouton sur le thermostat en le passant au travers de l'élargissement de la grille réalisé à l'étape 2.
4. Branchez le thermostat à l'appareil selon le diagramme de câblage de cette instruction.



# INSTRUCTIONS

## Option - Thermostat Kit

THE INSTALLATION MUST BE EXECUTED BY A QUALIFIED TECHNICIAN




### CAUTION

**DISCONNECT ALL POWER SUPPLIES  
BEFORE WORKING ON ANY CIRCUIT.**

#### INSTALLATION

1. Screw thermostat on the left (standard) or right end side of the front grille.
2. Use pliers to widen the grille to clear the knob.
3. Insert the knob onto thermostat by passing it through the enlargement of the grille made in step 2.
4. Connect the thermostat to the unit according to the wiring diagram of this instruction.

#### Thermostat unipolaire/ Single-pole thermostat



#### Thermostat bipolaire/ Double-pole thermostat

